



**NOTES:**

1. Concrete blocking is to be formed to ensure accesibility to fittings and poured against undisturbed earth.
2. Fittings are to be completely wrapped with plastic, prior to pouring concrete.
3. Concrete to be minimum 3,000 psi. @ 28 days.

**4" to 12" STANDARD TAPPING SLEEVE and VALVE ASSEMBLY**